INU

H

STEP

S/817/62/005/000/005/012 A006/A101

AUTHORS:

Putilin, Yu. M., Ponomarev, V. D., Milov, A. I., Dautova, L. I.

TITLE:

Thermographical investigation of the K2TiF6-NaCl-TiO2 system

SOURCE:

Akademiya nauk Kazakhskoy SSR. Institut metallurgii i obogashcheniya. Trudy. v. 5, 1962, Tsvetnaya metallurgiya, 82 - 94

TEXT: Using Kurnakov's thermal method the authors investigated the phase diagram of the K₂TiF₆-NaCl-TiO₂ system near binary eutectics K₂TiF₆-NaCl and K₂TiF₆-TiO₂. Batches of these substances were mixed, remelted and heated in platinum crucibles or blocks placed in a pyrometrical apparatus. After thermographical inspection thermograms of 78 compositions were taken. On the basis of results obtained from thermographical, roentgenostructural and crystallographical analyses a phase diagram of the system and phase diagrams of the binary systems were plotted. A spatial diagram of the system in the investigated range in presented and described. Polythermic cross-sections of the system are given at a constant 1-, 2-, 3- and 4-% content of titanium dioxide. A fusibility diagram

Card 1/4

Thermographical investigation of the ...


S/817/62/005/000/005/012 A006/A101

of the system is plotted on the concentration triangle and the boundaries of lamination zones are determined (Figure 13). The behavior of the basic component of the alloys - potassium fluorotitanate - was analyzed. On the basis of previous data, obtained by Kolómitskiy, Milov, Ponomárev and Putilin, it is assumed that this component is present in three polymorphous forms. For pure potassium fluorotitanate the following modifications are to be considered: δ - stable in a range from room temperature to 380°C; γ - stable in a 280 - 640°C range; β - stable at temperature over 640°C. Starting from 680°C noticeable dissociation begins. Full melting takes place at about 850°C. There are 17 figures and 1 table.

S/817/62/005/000/005/012 A006/A101

Thermographical investigation of the...

Figure 13. Fusibility diagram of the K_2TiF_6 -NaCl- TiO_2 system




Card 3/4

Thermographical investigation of the ...

S/817/62/005/000/005/012 A006/A101

Figure 13 (continued)



Card 4/4